



MZ1 series

MZ1 series

Pearl White



MZ1-001
1Gang 1way switch
MZ1-002
1Gang 2way switch



MZ1-003
2Gang 1way switch
MZ1-004
2Gang 2way switch



MZ1-005
3Gang 1way switch
MZ1-006
3Gang 2way switch



MZ1-007
DoorBell Switch



MZ1-008
1Gang 1way switch
MZ1-009
1Gang 2way switch



MZ1-010
2Gang 1way switch
MZ1-011
2Gang 2way switch



MZ1-012
DoorBell Switch



MZ1-013
Schuko Socket 2P+T



MZ1-014
French 2P Socket



MZ1-015
2P Socket



MZ1-016
1 In 1 Out TV socket



MZ1-017
Telephone socket
MZ1-018
1P Computer socket



MZ1-019
Dimmer switch



MZ1-019
Double Schuko Socket



MZ1-019
Double French Socket



MZ1-019
Double Socket