

L53 SERIES

White Gold Grey Black

SWITCH
AND SOCKET



L53-001
1 Gang 1 Way Switch



L53-003
2 Gang 1 Way Switch

L53-002
1 Gang 2 Way Switch

L53-004
2 Gang 2 Way Switch



L53-005
3 Gang 1 Way Switch



L53-007
4 Gang 1 Way Switch

L53-006
3 Gang 2 Way Switch

L53-008
4 Gang 2 Way Switch



Continue to break through the limit,
just to let you enjoy a
better product; continues to break boundaries,
only to provide you with more choice.



L53-028
TV socket



L53-029
TEL socket



L53-030
Data Socket(Cat4/Cat6)



L53-031
Satellite Socket



L53-032
TV+Satellite Socket



L53-033
TV+Tel Socket



L53-034
TV+Data Socket



L53-035
Tel+Data Socket



L53-036
Double Data Socket



L53-037
Light Dimmer 500W
L53-038
Light Dimmer 1000W



L53-009
Door Bell Switch



L53-011
20A Water Heater Switch



L53-012
45A A/C Switch



L53-013
1 Gang 2 Pin Socket



L53-014
1 Gang 4 Pin Socket




L53-039
Fan Dimmer



L53-041
Fan Dimmer with Switch



L53-042
Blank Cover 3*3



L53-043
Blank Cover 3*6



L53-015
2 Gang 4 Pin Socket



L53-016
13A Socket



L53-017
13A Switched Socket
with Light



L53-019
15A Switched Socket
with Light




L53-020
13A Multi Switched Socket
with Light



L53-044
Double 13A Switched Socket with Light



L53-047
Double 13A Switched Socket +
USB&TypeC with Light



L53-048
Double 13A Multi Switched Socket
with Light



L53-021
5 Pin Multi Switched Socket
with Light



L53-023
13A Switched Socket +
USB&TypeC with Light



L53-025
13A Multi Switched Socket +
USB&TypeC with Light




L53-026
16A European Socket




L53-027
16A French Socket



L53-050
Double 13A Multi Switched Socket +
USB&TypeC with Light



L53-051
45A A/C Switch 3*6



L53-052
Cooker Unit 3*6